



**Refillable EKO
capsules.sk for
Cafissimo® SEALPOD
coffee machines
instructions**

Instructions for use

How to use the SEALPOD capsule?

1. Fill the capsule with 9 grams of ground coffee up to the first inner edge.
2. Gently press the coffee in the capsule, do not press it hard, this could cause a weak flow of coffee through the capsule.
3. Put on the silicone lid.
4. The capsule is ready for regular use. Then follow the instructions for use of your coffee machine.

Tips for using the product

- Make sure that the pre-prepared hole is correctly positioned, the needle must fit exactly into the hole.
- Fill the capsule with 9 - 10 grams of finely ground coffee.
- If you grind your own coffee, choose a grinder with grinding stones and a grinding thickness slightly coarser than classic espresso.
- If you use finely ground coffee or prepare tea, we recommend using a paper filter - it will remove even the smallest particles.

How to use the product

For proper use, it is necessary to follow the instructions for use exactly. Incorrect use of the product can lead to damage to the coffee machine. The seller is not responsible for damage caused by incorrect use of the product.

The product is intended for use only in Cafissimo® coffee machines. This is not an original product from Tchibo. Cafissimo® is a registered trademark of Tchibo.

Do not expose the product to cold, dust and fire. The product is not intended for washing in a dishwasher. After each use, the product must be disassembled and rinsed by hand in water, detergent can also be used. Disassemble the capsule only after it has cooled down. You could get burned.

Materials used

- capsule: 304 stainless steel
- lid: silicone rubber (BPA-free)

Warranty and how to use the product

Products are covered by the standard statutory warranty period. This warranty is non-transferable and financial compensation in cash is not possible. The warranty does not apply to products that have been used in a manner other than that specified in these instructions for use.

The warranty also does not cover:

- Damage resulting from improper use, neglect of care, or any other use for purposes not listed in this manual.
- Damage to appearance, damage caused by corrosion or gradual wear and tear.

Any intervention or repair by unauthorized persons results in the voiding of the product warranty.

Seller and importer: NajTrade s.r.o., Húskova 31, 04023 Košice, IČO: 50590502.

