



Mlynko

Instructions for use

Setting the grinding thickness:

1. Disconnect the lower coffee dispenser.
2. Turn the grinder upside down. Set the desired grinding thickness with a plastic nut.
3. By pulling you set fine grinding, by releasing coarse grinding.
4. Do not pull too tight as this may cause the coffee bean to jam in the mechanism. If it is not possible to turn the crank after tightening or the or the crank rotates, loosen the nut.

Instructions to use:

1. Disconnect the crank and open the lid at the top of the grinder.
2. Fill the coffee beans in the required amount.
3. Close the lid and install the crank.
4. Swirl the crank until the coffee is completely ground.
5. To keep the maximum freshness of coffee, we recommend grinding only the amount of coffee you would need.
6. Hold the grinder by the middle part (not the coffee container) during grinding, the container could break off during intensive grinding.



Warranty and how to use the grinder:

We recommend discarding the first 2 batches of grinding before first use (you can use cheaper coffee). The first grinding "sets" the grinder to the right smell of coffee, the coffee from the first grinding absorbs the production smell of the grinder.

For correct use, follow the instructions for use. The seller is not liable for damage caused by improper use of the product.

Mlynko is not intended for cleaning in a dishwasher. Do not rinse the grinding mechanism; clean it with a dry brush. The grinder is only intended for grinding coffee, other beans (eg spices) could damage it.

Materials used:

- body, crank handle: 304 stainless steel,
- grinding mechanism: porcelain,
- auxiliary components: plastic 5-PP.

Warranty and how to use the product

Products are covered by the standard statutory warranty period. This warranty is non-transferable and financial compensation in cash is not possible. The warranty does not apply to products that have been used in a manner other than that specified in these instructions for use.

The warranty also does not cover:

- Damage resulting from improper use, neglect of care, or any other use for purposes not listed in this manual.
- Damage to appearance, damage caused by corrosion or gradual wear and tear.

Any intervention or repair by unauthorized persons results in the voiding of the product warranty.

Seller and importer: NajTrade s.r.o., Húskova 31, 04023 Košice, IČO: 50590502.

