



**Refillable EKO
capsules.sk SEALPOD
for Nespresso ®**

Instructions for use

How to use a SEALPOD capsule?

1. Fill the capsule with coffee to the brim, pour out the excess coffee.
2. Gently press the coffee in the capsule, do not press it hard, this could cause poor coffee flow through the capsule.
3. Glue the SEALPOD lid. For a perfect seal, glue the lid only to the clean edge of the capsule without coffee beans.
4. The capsule is ready for regular use. Then follow the instructions for use of your coffee machine.

TIP: If you want to fill the capsule with coffee in advance, we recommend placing a rubber cover on the bottom of the capsule, it will help you keep the coffee in the capsule fresh for as long as possible.

What coffee to use in the SEALPOD capsule?

We recommend using finely ground coffee. If you grind your own coffee with a grinder, we recommend using a grinder with grinding stones (ceramic), not with knives. Grinding stones grind the coffee finer and more precisely.

Method of use

For proper use, it is necessary to follow the instructions for use exactly. Incorrect use of the product can lead to damage to the coffee machine, hot water and coffee leaking out of the coffee machine. The seller is not responsible for damage caused by incorrect use of the product.

Do not expose the product to cold, dust and fire.

The product is intended for use only in Nespresso® coffee machines. This is not an original product from Nestlé. Nespresso® is a registered trademark of Nestlé

After each use, it is necessary to remove the lid and wash the capsule. Be careful of hot water in the capsule when disassembling.

Materials used

- capsule: 304 stainless steel
- replacement seal: silicone rubber
- adhesive lids: aluminum foil
- scoop, cover: food grade polypropylene (BPA free)

Warranty and how to use the product

Products are covered by the standard statutory warranty period. This warranty is non-transferable and financial compensation in cash is not possible. The warranty does not apply to products that have been used in a manner other than that specified in these instructions for use.

The warranty also does not cover:

- Damage resulting from improper use, neglect of care, or any other use for purposes not listed in this manual.
- Damage to appearance, damage caused by corrosion or gradual wear and tear.

Any intervention or repair by unauthorized persons results in the voiding of the product warranty.

Seller and importer: NajTrade s.r.o., Húskova 31, 04023 Košice, IČO: 50590502.

