



WACACO

Digital Scale Wacaco Exagram

Instructions for use

Power on/off

The power button is located at the bottom of the device. To turn on/off, hold the button for 1 second.

Weighing

Place the object to be weighed in the center of the weighing platform. Make sure that the display shows 0.00g before weighing (use the tare function if necessary). The maximum weight of the object to be weighed is 2000g.

Changing the unit of measurement

Press the "timer" button twice to change the unit of measurement, the scale will confirm this action with a beep.

Tare function

If you are weighing coffee in a portafilter, for example, first place the portafilter itself on the weighing platform. Press the tare button to read the portafilter value. Then pour the coffee and measure its weight as usual.

Stopwatch

Press the "timer" button to start the stopwatch. Press it again to stop the stopwatch. Press and hold the "timer" button for two seconds to reset the stopwatch.

Warning

- This is a precision instrument. Handle it with care to avoid decalibration.
- Do not use in wet or humid environments.
- Make sure that no liquid spills outside the silicone pad.
- Do not weigh objects heavier than 2 kg (2000g), as this could damage the scale.
- Use only fully charged batteries. Discharged batteries may display incorrect weighing values.
- If the product is not to be used for a long period of time, remove the batteries.
- When storing the product, do not place any objects on the scale, preferably in the box provided.
- Do not expose the product to radiant heat.
- When weighing, place the product on a flat surface.

Disposal

Dispose of the appliance at a suitable collection point for electrical waste.

Safety

The product meets CE and FC safety standards

Warranty and how to use the product

Products are covered by the standard statutory warranty period. This warranty is non-transferable and financial compensation in cash is not possible. The warranty does not apply to products that have been used in a manner other than that specified in these instructions for use.

The warranty also does not cover:

- Damage resulting from improper use, neglect of care, or any other use for purposes not listed in this manual.
- Damage to appearance, damage caused by corrosion or gradual wear and tear.

Any intervention or repair by unauthorized persons results in the voiding of the product warranty.

Seller and importer: NajTrade s.r.o., Húskova 31, 04023 Košice, IČO: 50590502.

