

**KAFFE
LOGIC**

Kaffelogic Boost Kit

Instructions for use


What's In The Box

- 1x Short BOOST roast chamber extension ring.
- 1x Tall BOOST roast chamber extension ring.
- 1x BOOST Activation code.


Activation

1. Open Studio on your laptop.
2. Plug the USB-C cable into your laptop and the roaster.
3. Turn the roaster on.
4. In Studio, click on Help > Activate features.
5. In the pop-up window enter the code that is on the back of your Boost activation card and click activate.
6. The Status will change from 'Inactive' to 'Active'. If it does not then please contact customer support.

How To Use



Weigh your desired load of coffee (10g increments).




If you are roasting a larger load, insert a BOOST ring.

Pour your coffee load into the roaster.


Press ▶ to load
K-logic classic



Select your profile and press *Start*.



You will be prompted to select your load size with the + and - buttons.



Press *Start* to begin the roast.



Further Information

- The included BOOST rings are extensions that will stop roasted beans from falling out when you remove the chaff collector. You can roast smaller batches without them.
- If you want to roast a standard, or “non-boost” roast, select the 120g load size and roast as normal.
- If you want to check your bean movement before roasting, use Fan Preview with your coffee loaded in the roaster. After selecting your profile, press the menu button and select Fan Preview. This will start the fan with no heat to make sure the beans are moving sufficiently.

Larger Batch Sizes

Some coffees may not roast identically at larger load sizes. Usually this may apply to high density, small screen size or lower quality graded coffees. If you experience ‘bean lock’ (beans motion stops during the roast), scorching or increased unevenness at higher load sizes, simply roast smaller load sizes until you hit the sweet spot for your particular coffee.

Support

For any assistance, please reach out to support at kaffellogic.com/help.

Warranty and how to use the product

Products are covered by the standard statutory warranty period. This warranty is non-transferable and financial compensation in cash is not possible. The warranty does not apply to products that have been used in a manner other than that specified in these instructions for use.

The warranty also does not cover:

- Damage resulting from improper use, neglect of care, or any other use for purposes not listed in this manual.
- Damage to appearance, damage caused by corrosion or gradual wear and tear.

Any intervention or repair by unauthorized persons results in the voiding of the product warranty.

Seller and importer: NajTrade s.r.o., Húskova 31, 04023 Košice, IČO: 50590502.

